


# PAREXDIRECT CAVITY ONTO STEEL FRAME

# PDCS0209A

WINDOW PROCEDURE 1 OF 5



This detail is for general guidance only and is not project specific. Always refer to the project architect details and the PAREX project specific specification.



Leave breather membrane loose for Step 2

Parex WeatherTech Weatherseal or proprietary breather membrane (by others, if required)

Parex WeatherTech Weatherseal taken into the opening in one continuous application. When there is a breather membrane seal all gaps and voids against the timber or steel frame with the WeatherTech Weatherseal. Where there are large voids embed with 352 SA mesh to provide additional strength

The general principles of this detail will apply to all forms of openings. For unusual applications contact Parex for additional guidance.

System: PAREXDIRECT onto Steel Frame  
Application: Window installation 1 of 5 - Sealing the breather membrane within an opening  
Drawing No: PDCS0209A (In addition to this detail please also refer to details – PDCS0209 1 to 5)  
Date: November 2015



The information provided in this document results from our knowledge of the products and our experience. On-site results may vary, in particular according to the product application methods adopted. Where application methods not covered by this document are used, customers must request specific additional information and/or carry out a representative test before using the products. The above-mentioned information in no way constitutes a warranty relative to the use of the products. Our general terms and conditions of sale shall prevail, in any event, on the information provided in this document. Prior to application, customers and users are requested to check that they have the latest version of this document.